

<b>Alpha 91B Settings @ 1500w Output</b>			
<b>MHz</b>	<b>BAND</b>	<b>TUNE</b>	<b>LOAD</b>
1,8	1,8	51	2
2,0	1,8	15	65
3,5	3,5	78	32
4,0	3,5	55	60
7,15	7	50	25
10,13	10	70	56
14,2	14	38	48
18,1	18-21	83	47
21,2	18-21	33	67
24,9	24-28	71	60
28	24-28	31	71
29,7	24-28	20	80

This chart replaces the one on page 11 of the Alpha 91B Operating Manual (21-MAY-99)